





Important safety instructions:


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
P1	Desk Top		1
P2	Left Leg	 (P2)	1
P3	Right Leg	 (P3)	1
P4	Back Stretcher		1


**Hardware List**

Item	Description		QTY
H1	Bolts 1 Ø1/4"×3/4"L		4
H2	Bolts 2 Ø1/4"×3/4"L		8
H3	Lock Washers 1/4"		8
H4	Flat Washers 1/4"		8
H5	Allen Wrench 1/4"		1
H6	Screw Driver		Not included





Assembly Procedures:


Step 1. Assemble the desk on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach the left and right leg (P2 & P3) to the back stretcher (P4) as shown below image 1.

- (H1)x4 Bolts Ø1/4"×3/4"L
 (H5)x1 Allen Wrench 1/4"




Step 2. Loosely attach the assembled legs and stretcher to the bottom of desk (P1) as shown below image 2.

- | | | |
|--------|--|---|
| (H2)x8 | Bolts $\varnothing 1/4 \times 3/4$ " L |  |
| (H3)x8 | Lock Washers 1/4" |  |
| (H4)x8 | Flat Washers 1/4" |  |
| (H5)x1 | Allen Wrench 1/4" |  |



Step 3.

- 1) Securely tighten all bolts. Turn the assembled desk to an upright position.
- 2) Remove the handles from the back of drawer front panel by unscrewing the bolts with screw driver (not provided).
- 3) Reattach the handles to the front of drawer front panel using bolts as shown below.
- 4) To level desk. If there is a gap between a leg and the floor, please adjust the adjustable leveler up or down under each leg.
- 5) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase