

**Important safety instructions:**


- Please carefully read all instructions before assembling the chest.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

**Parts List**

Item	Description	QTY
A	Chest	1
B	Feet	4


**Hardware List**

Item	Description	QTY
a	Bolts Ø1/4"x 5/8"	16
b	Lock Washers 1/4"	16
c	Flat Washers 1/4"	16
d	Allen Wrench 1/4"	1

**Assembly Procedures:**

Step. Assemble the chest on a flat, soft surface such as carpet or cloth to prevent scratching the finish.

- 1) Attach each foot (B) to the bottom of chest (A) using bolts (a), lock washers (b) and flat washers (c) as shown below. Securely tighten all bolts with Allen wrench (d).
- 2) Turn the assembled chest to an upright position. Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchase