

**Important safety instructions:**

- Please carefully read all instructions before assembling the chest.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

**Pre-assembly:**


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

**Parts List**

Item	Description	QTY
P1	Chest	1
P2	Feet	4

**Hardware List**



Item	Description	QTY
H1	Bolts Ø1/4"x1-1/2"	8
H2	Lock Washers 1/4"	8
H3	Flat Washers 1/4"	8
H4	Allen Wrench 1/4"	1

**Assembly Procedures:**

Step 1. Assemble the chest on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.

- 1) Attach feet (P2) to the bottom of chest (P1) as shown below. Securely tighten all bolts with Allen wrench (H4).
- 2) Turn the assembled chest to an upright position.
- 3) Leveler adjustment: Leveler are pre-installed on the legs and adjust as needed to make sure the chest is level.
- 4) Assembly is complete. Failure to follow these instructions may cause the bolts to misalign during assembly.

(H1)x8	Bolts	
(H2)x8	Lock Washers	
(H3)x8	Flat Washers	
(H4)x1	Allen Wrench	



**ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.**

Thank you for your purchase