

Important safety instructions:


- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
P1	Chest	1
P2	Side Frames	2
P3	Top Rails	2
P4	Stretchers	2

**Hardware List**


Item	Description	QTY
H1	Bolts Ø1/4"x5/8"	16
H2	Bolts Ø1/4"x1"	6
H3	Lock Washers 1/4"	22
H4	Flat Washers 1/4"	22
H5	Allen Wrench 1/4"	1

Assembly Procedures:

Step 1. Assemble the chest on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.


Loosely attach side frames (P2) to the top rails (P3) and stretchers (P4) using bolts (H1), lock washers (H3) and flat washers (H4) as shown below.

(H1)x16 Bolts (H4)x16 Flat Washers
 (H3)x16 Lock Washers (H5)x1 Allen Wrench




Step 2. **Loosely** attach the assembled base to the bottom of the chest (P1) using bolts (H2), lock washers (H3) and flat washers (H4) as shown below

(H2)x6 Bolts 
(H3)x6 Lock Washers 
(H4)x6 Flat Washers 



Step 3.

- 1) Securely tighten all the bolts with Allen wrench (H5).
- 2) Turn the assembled chest to an upright position.
- 3) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase

Page 2 of 2