













LULU DINING CHAIR



Assembly instructions:

PARTS LIST		
No.	DESCRIPTION	IMAGE
P1	CHAIR BACK	
P2	SEAT FRAME	
P3	FRONT LEG	

HARDWARE LIST		
No.	DESCRIPTION	IMAGE
H1	BOLT (26.3x70mm)	
H2	SPRING WASHER	
H3	FLAT WASHER	
H4	ALLEN KEY	
H5	BOLT (26.3x38mm)	
H6	HEX NUT	
H7	SPRING WASHER	
H8	FLAT WASHER	
H9	WRENCH	

NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy assembly should be performed by two people.



ASSEMBLED COMPLETE