

Important safety instructions:


- Please carefully read all instructions before assembling the chair.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description	QTY
A	Chair Top	1
B	Front legs with label "Front"	2
C	Back Legs with label "Back"	2




Hardware List

Item	Description	QTY
a	Bolts Ø5/16*2" L	8
b	Lock Washers 5/16"	8
c	Flat Washers 5/16"	8
d	Allen Wrench 5/16"	1

Assembly Procedures:

Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach back legs (C) with label "Back" to the bottom of chair top (A) as shown below. **Note: do not tighten them fully during assembly.**

- (a)x4 Bolts
- (b)x4 Lock Washers
- (c)x4 Flat Washers
- (d)x1 Allen Wrench



Step 2. Attach front legs (B) with label "Front" to the bottom of chair top (A) as shown below. **Note: do not tighten them fully during assembly.**

(a)x4 Bolts




(b)x4 Lock Washers



(c)x4 Flat Washers




(d)x1 Allen Wrench



Step 3.

- 1) Turn the assembled chair to an upright position. Make sure the chair is level and then securely tighten all bolts completely with Allen wrench (d).
- 2) Assembly is complete.

(d)x1 Allen Wrench



Caution: Failure to follow these instructions may cause the bolts to misalign during assembly.

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase