



BENTNER DINING SIDE CHAIR

Assembly instructions:

PARTS LIST			
No.	DESCRIPTION	IMAGE	QTY
P1	CHAIR BACK		1
P2	SEAT FRAME		1
P3	FRONT LEG (LEFT)		1
P4	FRONT LEG (RIGHT)		1

HARDWARE LIST			
No.	DESCRIPTION	IMAGE	QTY
H1	FLAT WASHER		9
H2	SPRING WASHER		9
H3	BOLT (Ø 6.3x50mm)		4
H4	ALLEN KEY		1
H5	BOLT (Ø 6.3x38mm)		1
H6	HEX NUT		4
H7	WRENCH		1



NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy assembly should be performed by two people.