

ASSEMBLY INSTRUCTIONS

Description: Margot Accent chair




Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
P1	Chair Back		1
P2	Seat Cushion		1
P3	Front Legs		2

Hardware List





Item	Description		QTY
H1	Short Bolts Ø5/16"x1-3/4"		1
H2	Medium Bolts Ø5/16"x2-1/2"		4
H3	Long Bolts Ø5/16"x3-1/2"		4
H4	Lock Washers 5/16"		9
H5	Flat Washers 5/16"		9
H6	Allen Wrench 5/16"		1




Caution: Bolt "H3" are the longest bolts and are used to attach the back legs of the chair. Be careful not use them in another location or it could cause damage to your chair.




Assembly Procedures:


Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach seat cushion (P2) to chair back (P1) using short bolts (H1), long bolts (H3), lock washers (H4) and flat washers (H4).

- (H1)x1 Short Bolts 
- (H3)x4 Long Bolts 
- (H4)x5 Lock Washers 
- (H5)x5 Flat Washers 
- (H6)x1 Allen Wrench 




Step 2. Loosely attach front legs (P3) to seat cushion (P2) using medium bolts (H2), lock washers (H4) and flat washers (H5).

- (H2)x4 **Medium Bolts** 
(H4)x4 **Lock Washers** 
(H5)x4 **Flat Washers** 



Step 3.

- 1) Turn the assembled chair to an upright position. Make sure the chair is level and securely tighten all bolts with Allen wrench (H6).
- 2) Assembly is complete.



Caution: Failure to follow these instructions may cause the bolts to misalign during assembly.

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase