

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List


Item	Description	QTY
P1	Top Chest	1
P2	Legs	4
P3	Bottom Panel	1
P4	Feet	4

Hardware List


Item	Description	QTY
H1	Anti Tip Kit	1 SET
	Screw Driver	Not Provided

Assembly Procedures:

Step 1: Assemble the **chest** on the flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the legs (P2) to the top chest (P1) as shown below:




Step 2: Loosely attach bottom panel (P3) and feet (P4) to the legs (P2) as shown below:



Step 3:

1. Turn the assembled **chest** to an upright position.
2. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

Anti Tip Kit package has been attached to the back of product. Please read guideline thoroughly and then install immediately to prevent product from tipping.



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase