

Description: Loveseat


Important safety instructions:


- Please carefully read all instructions before assembling the Chair
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

No.	DESCRIPTION	IMAGE	QTY
P1	Chair		1
P2	Legs		4






Hardware List


No.	DESCRIPTION	IMAGE	QTY
H1	Plastic washer		4

Assembly Procedures:

Step1. Assemble the loveseat on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.
Take out the legs under seat cushion.



Step 2: Turn over the loveseat, screw in the legs (P2) into the screw holes underneath the bottom by using plastic washers (H1). By rotating legs clockwise, then upright the loveseat on a level surface.



Use and Care instructions for your Madison Park Signature Furniture

Your wood furniture can be cleaned using a damp soft cotton cloth to wipe it down, then wipe dry with a second soft cotton cloth. Some spray and liquid furniture polishes can change the sheen (how shiny your furniture is) of the finish. If you plan to use a product like this to clean your furniture you should first test it in an inconspicuous part of the furniture. Upholstery should be cleaned using a quality product intended for furniture upholstery. It is best to not place your furniture in direct sunlight as it can fade the finish over time. Always lift your furniture when moving it as dragging it can cause damage.

Thank you for your purchase