










Important safety instructions:


- Please carefully read all instructions before assembling the chair.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:






- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

No.	DESCRIPTION	IMAGE	QTY
P1	Front Legs		2
P2	Right Back Leg		1
P3	Left Back Leg		1
P4	Middle Leg		1
P5	Left Seat cushion		1
P6	Middle Seat Cushion		1
P7	Right Seat cushion		1
P8	Pillows		3
P9	Sofa		1




Hardware List


No.	DESCRIPTION	IMAGE	QTY
H1	Bolts $\phi 5/16 \times 2-12/16$ "		8
H2	Lock Washers $\phi 5/16$ "		8
H3	Flat Washers $\phi 5/16$ "		8
H4	Allen Wrench $\phi 5/16$ "		1
H5	Plastic Washer		1

Assembly Procedures:


Step 1. Remove legs&hardwares from underneath seat cushion.




Step 2. Place sofa(P9) upside down onto a protective cloth. Open black fabric on the bottom of sofa. Using bolts (H1), lock washers (H2), and flat washers (H3), connect legs(P1,P2,P3) to sofa . Tighten bolts (H1) with Allen Wrench (H4). Replace black fabric.



Step 3. Place washers(H5) on middle leg(P4) and attach to base by screwing clockwise into corresponding hole.



Step 4. Place sofa upright on a level surface. Ensure the seat cushions(P5&P6&P7) and the pillows(P8) are properly attached. Assembly is complete.



ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PREIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

USE AND CARE INSTRUCTIONS FOR YOUR MADISON PARK SIGNATURE FURNITURE

- Your wood furniture can be cleaned using a damp soft cotton cloth to wipe it down, then wipe dry with a second soft cotton cloth.
- Some spray and liquid furniture polishes can change the sheen (how shiny your furniture is) of the finish.
- If you plan to use a product like this to clean your furniture you should first test it in an inconspicuous part of the furniture.
- Upholstery should be cleaned using a quality product intended for furniture upholstery.
- It is best to not place your furniture in direct sunlight as it can fade the finish or fabric over time.
- Always lift your furniture when moving it as dragging it can cause damage.

Thank you for your purchase