











HELENA ROUND DINING TABLE

Assembly instructions:

PARTS LIST			
No.	DESCRIPTION	IMAGE	QTY
P1	TABLE TOP		1
P2	PEDESTAL		1
P3	CROWN CURVED LEG		4
P4	BASE		1
P5	MOUNTING PLATE		1





HARDWARE LIST			
No.	DESCRIPTION	IMAGE	QTY
H1	BOLT (ø5/16" x 60mm)		6
H2	BOLT (ø5/16" x 35mm)		10
H3	FLAT WASHER (ø5/16" x 19mm)		16
H4	SPRING WASHER (ø5/16" x11mm)		16
H5	ALLEN KEY (M4)		1

NOTE: PO # is located underneath/ at the back side of each item. Please be prepared to provide this # should any claim be necessary.

CAUTION: Item is heavy. Assembly should be performed by two people.

DISCLAIMER:

When properly assembled, this item is safe for intended use. Seller is not liable for any damages resulting from item being improperly assembled after purchase.



ASSEMBLY COMPLETED

ADDITIONAL NOTE ABOUT SAFETY:
BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase