



Assembly Instruction---Accent Chair


PARTS #	PARTS NAME	DRAWING	QTY
P1	Front Legs		2
P2	Back Legs		2
P3	Chair		1
P4	Seat Cushion		1

Hardware#	PARTS NAME	DRAWING	QTY
H1	Plastic Washers		4

1. Turn the chair upside down and lay on protective carpet. Open the black fabric of the bottom and take out the legs and plastic washer



2. Place plastic washer into corresponding hole and attach to chair base (P3) by screwing clockwise



3. Place the chair upright and place the seat cushion (P4) on the chair. Assembly is complete.

