


Assembly Instruction--Catherine Accent Chair


| PARTS # | PARTS NAME | DRAWING | QTY |
|---------|------------|---------|-----|
| P1 | FRONT LEGS | | 2 |
| P2 | BACK LEGS | | 2 |
| P3 | CHAIR | | 1 |

| Hardware# | PARTS NAME | DRAWING | QTY |
|-----------|------------------------|---------|-----|
| H1 | Bolts φ5/16*1" | | 8 |
| H2 | Lock Washers φ5/16" | | 8 |
| H3 | Flat Washers φ5/16" | | 8 |
| H4 | Allen Wrench φ1/4" | | 1 |

1. Turn the chair upside down and lay on protective carpet, open the black fabric on bottom and take the legs and hardware .



2. Turn over the chair and lay on protective carpet ,using bolts (H1), lock washers (H2), flat washers (H3), connect legs(P1,P2) to chair (P3). Tighten bolts (H1) with Allen Wrench (H4).



3. Place the chair upright on a level surface.

Assemble is complete.

