


Assembly Instruction--Accent Chair


PARTS #	PARTS NAME	DRAWING	QTY
P1	FRONT LEGS		2
P2	BACK LEGS		2
P3	CHAIR		1

Hardware#	PARTS NAME	DRAWING	QTY
H1	Bolts φ5/16*2"		8
H2	Lock Washers φ5/16"		8
H3	Flat Washers φ5/16"		8
H4	Allen Wrench φ1/4"		1

1. Turn the chair upside down and lay on protective carpet, then take the legs and hardware package from the zipper pocket on bottom.



2. Using bolts (H1), lock washers (H2), flat washers (H3), connect legs (P1, P2) to chair (P3). Tighten bolts (H1) with Allen Wrench (H4).



3. Place the chair upright on a level surface. Assemble is complete.

