



ASSEMBLY INSTRUCTIONS

Description: Markus Accent Ottoman




Important safety instructions:


- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Seat Cushion		1
P2	Metal Stretcher		1
P3	Legs		4




Hardware List

Item	Description		QTY
H1	Bolts	Ø1/4" * 1/2"	4
H2	Bolts	Ø1/4" * 1"	8
H3	Lock Washers	Ø1/4"	8
H4	Flat Washers	Ø1/4"	8
H5	Allen Wrench	1/4"	1



DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Step 1. Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. To locate the hardware, please turn the chair upside down, you will find the components beneath the fabric cover that is secured by zipper underneath the seat cushion. Legs and hardware box could be located beneath the fabric cover.



Step 2. Loosely attach the legs (P3) to the metal stretcher (P2) as shown below. Do not tighten at this step.


- (H1)x4 Bolts Ø1/4" *1/2" 
- (H5)x1 Allen Wrench 



Step 3.

- 1) Attach the assembled legs (P3) to the bottom of seat cushion (P1) as shown below.
- 2) Turn the assembled ottoman to an upright position. Make sure the assembled ottoman is level and securely tighten all the bolts with Allen wrench (H5).
- 3) **Failure to follow these instructions may cause the bolts to misalign during assembly.** Assembly is complete.

- (H2)x8 Bolts Ø1/4" *1" 
- (H3)x8 Lock Washers Ø1/4" 
- (H4)x8 Flat Washers Ø1/4" 
- (H5)x1 Allen Wrench 



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase