



ASSEMBLY INSTRUCTIONS

Description: Demi Accent Bench




Important safety instructions:

- Please carefully read all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.







Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any plastic protective packaging.

Parts List

Item	Description		QTY
P1	Seat Cushion		1
P2	Side Frames		2
P3	Stretcher		1

Hardware List


Item	Description		QTY
H1	Bolts Ø5/16" * 1-1/4"L		4
H2	Lock Washers Ø5/16"		4
H3	Flat Washers Ø5/16"		4
H4	Allen Wrench 5/16"		1
H5	Screws #8*1-1/4"		2
H6	Screw Driver		Not included






Assembly Procedures:

Step 1. Assemble the bench on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach one side frame (P2) to the bottom of seat cushion (P1) using bolts (H1), lock washers (H2) and flat washers (H3) as shown below.


- (H1)x2 Bolts
- (H2)x2 Lock Washers
- (H3)x2 Flat Washers
- (H4)x1 Allen Wrench



Step 2. Insert stretcher (P3) between two side frames (P2). Loosely attach second side frame (P2) to the bottom seat cushion (P1) using bolts (H1), lock washers (H2) and flat washers (H3) as shown below.

(H1)x2	Bolts	
(H2)x2	Lock Washers	
(H3)x2	Flat Washers	


Note: Make sure the holes on the stretcher (P3) facing up when assembling this step.



Step 3.

- 1) Tighten all screws (H5) with screw driver (not provided) ..
- 2) Turn the assembled bench to an upright position.
- 3) Make sure the bench is level and securely tighten all the bolts with Allen wrench (H4).
- 4) Assembly is complete.

(H5)x2 Screws 



Caution: Failure to follow these instructions may cause the bolts to misalign during assembly.

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase