



ASSEMBLY INSTRUCTIONS

Description: Tristan Dining Chair

Important safety instructions:


- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description	QTY
P1	Chair Back	1
P2	Seat Cushion	1
P3	Front Legs	2



Hardware List

Item	Description	QTY
H1	Short Bolts Ø5/16"**2"	5
H2	Long Bolts Ø5/16"**3-1/2"	4
H3	Lock Washers 5/16"	9
H4	Flat Washers 5/16"	9
H5	Allen Wrench 5/16"	1

DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:

Step 1. Assemble the chair on a flat, soft surface such as a carpet or cloth to prevent scratching the finish.

Attach the seat cushion (P2) to the chair back (P1) as shown below.


(H1)x1 Short Bolts Ø5/16"**2"

(H2)x4 Long Bolts Ø5/16"**3-1/2"

(H3)x5 Lock Washers Ø5/16


(H4)x5 Flat Washers Ø5/16

(H5)x1 Allen Wrench Ø5/16




Step 2. Attach the front legs (P3) to the seat cushion (P2) as shown below.

(H1)x4 Short Bolts Ø5/16" *2" 
(H3)x4 Lock Washers Ø5/16 
(H4)x4 Flat Washers Ø5/16 
(H5)x1 Allen Wrench Ø5/16 



Step 3. Securely tighten all bolts with Allen wrench(H5). Turn the assembled chair to an upright position, make sure the chair is level, aligned properly. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



ADDITIONAL NOTE ABOUT SAFETY:

BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE.

THEY SHOULD BE INSPECTED AT LEAST EVERY 3 MONTHS AND RE-TIGHTENED AS NEEDED TO PREVENT DAMAGE OR INJURY, AND ENSURE STABILITY.

Thank you for your purchase