



# ASSEMBLY INSTRUCTIONS

## Description: Holls Console

### Important safety instructions:


- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

### Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

### Parts List

Item	Description	QTY
P1	Top Panel	1
P2	Shelf	2
P3	Left Side Frame	1
P4	Right Side Frame	1
P5	Drawer Box	1
P6	Knob	2



### Hardware List

Item	Description	QTY
H1	Long Bolt $\phi 1/4" * 1-1/4" L$	4
H2	Short Bolt $\phi 1/4" * 1/2" L$	5
H3	Medium Bolt $\phi 1/4" * 1" L$	12
H4	Lock Washer $1/4"$	4
H5	Flat Washer $1/4"$	4
H6	Allen Wrench $1/4"$	1
H7	Screw $\phi 5/32" * 3/4" L$	2
H8	Screwdriver (not provided)	1

### DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

### Assembly Procedures:

**Step 1.** Assemble the console on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Loosely attach the right side frame (P4) to top panel (P1) as shown below image 1.

(H3)x2 Medium Bolt  $\phi 1/4" * 1" L$  (H6)x1 Allen Wrench  $1/4"$

Image 1



Step 2. Pull out the drawer from the drawer box completely (P5), then attach the drawer box (P5) to top panel (P1). See below image 2.


(H1)x4 Long Bolt  $\phi 1/4" * 1-1/4" L$  

(H4)x4 Lock Washer 1/4" 

(H5)x4 Flat Washer 1/4" 

(H6)x1 Allen Wrench 1/4" 

Image 2




Step 3. Attach the shelves (P2) to right side frame (P4). See below image 3.

(H3)x4 Medium Bolt  $\phi 1/4" * 3/4" L$  

(H6)x1 Allen Wrench 1/4" 

Image 3




Step 4. Attach the left side frame (P3) to the top panel (P1) and shelves (P2). See below image 4.  
Securely tighten all bolts. Turn the assembled console to an upright position.

(H2)x5 Short Bolt  $\phi 1/4" * 1/2" L$  

(H3)x6 Medium Bolt  $\phi 1/4" * 1" L$  

(H6)x1 Allen Wrench 1/4" 

Image 4




Step 5.


- a) Remove the knobs (P6) from back of drawer front panel by unscrewing the bolts with screw driver (not provided) and then reattach to the drawer front by using bolts. See below image 5.
- b) To level console: If there is a gap between a leg and the floor, please adjust the adjustable leveler up or down which under each leg. See image 6.
- c) Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**

(H7)x2 Screw Ø5/32" \*3/4" L 

**Image 5**



**Image 6**



**All bottom of legs have  
adjustable leveler**

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

**Thank you for your purchase**