



ASSEMBLY INSTRUCTIONS

Description: Elora End Table




Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.





Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description		QTY
P1	Top Panel		1
P2	Leg		4
P3	Stretcher		1

Hardware List

Item	Description		QTY
H1	Bolts Ø1/4" x 15mm L		8
H2	Lock Washers Ø1/4"		8
H3	Flat Washers Ø1/4"		8
H4	Allen Wrench M4		1





DISCLAIMER:


WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.

Assembly Procedures:





Step 1: Assemble the Table on a flat, soft surface such as carpet or cloth to prevent scratching the finish.


Attach the Legs (P2) to the Top Panel (P1) do not fully tighten, as shown below.

- (H1)x4 Bolts Ø1/4" x 15mm L 
- (H2)x4 Lock Washers Ø1/4" 
- (H3)x4 Flat Washers Ø1/4" 
- (H4)x1 Allen Wrench M4 




Step 2: Attach the Stretcher (P3) to four Legs (P2) as shown below.

- (H1)x4 Bolts $\varnothing 1/4"$ x 15mm L 
- (H2)x4 Lock Washers $\varnothing 1/4"$ 
- (H3)x4 Flat Washers $\varnothing 1/4"$ 
- (H4)x1 Allen Wrench M4 



Step 3:

- 1) Securely tighten all the Bolts with Allen Wrench (H4).
- 2) Turn the assembled table to an upright position.
- 3) Assembly is complete. Failure to follow these instructions may cause the bolts to miss align during assembly.



To adjust the adjustable leveler. If there is a gap between a leg and the floor, please adjust the adjustable leveler up or down under each leg.

ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase