




Care Instructions

For your heated products

Wash Instructions



Wash by hand or separately in automatic washer



In automatic washer, use the cycle with the least agitation and normal spin speed, often labeled as Quick Wash or Delicate Cycle



Use cold water and a minimal amount of detergent



Remove immediately after spin cycle completes




Do not bleach

Dry Instructions




Hang to dry or dry separately in automatic dryer



In automatic dryer, tumble dry for 5 minutes only on medium or low temperature




Remove damp bedding from dryer, gently stretch to its original size, and drape or hang to finish drying



Do not use clothespins



Do not iron



Lay flat and run your fingers along the wire. Pay special attention to the top and bottom of the blanket where the wire bends. If any portion of the wire is twisted on itself, manually twist it back

Copyright ©2023 E&E Co. Ltd., Inc. All rights reserved.

[Terms of Service](#)