

ASSEMBLY INSTRUCTIONS

Description: Frazier Counter stool /barstool (adjustable height).

Important safety instructions:

- Please read carefully all instructions before assembly.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.

Pre-assembly:

- Do not discard any content until assembly is complete to avoid accidentally discarding small parts or hardware.
- Take out all parts and hardware from box.

Parts List

Item	Description	QTY
P1	Top	1
P2	Legs	3
P3	Metal Base	1
P4	Center Support	1
P5	Metal Ring	1

Hardware List


Item	Description	QTY
H1	Bolts Ø1/4" x 3/4"L	5
H2	Lock Washers 1/4"	5
H3	Flat Washers 1/4"x16	5
H4	Allen Wrench	1
H5	Flat Washers Ø30	1
H6	Nut	1
H7	Screw 1/8"x 1"L	6
H8	Screw 1/8"x 1-5/8"L	3
H9	Screw Driver	Not Provide

DISCLAIMER:

WHEN PROPERLY ASSEMBLED, THIS ITEM IS SAFE FOR INTENDED USE. SELLER IS NOT LIABLE FOR ANY DAMAGES RESULTING FROM ITEM BEING IMPROPERLY ASSEMBLED AFTER PURCHASE.


Assembly Procedures:

Step 1: Assemble the chair on a flat and soft surface either on a carpet or cloth to prevent the finish from scratching. Attach Legs (P2) to Metal Base (P3) then attach Metal Ring (P5) to Legs (P2), as shown below:




Step 2: Assemble the Screw (H8) to Leg (P2) then assemble the Screw (H7) to Leg (P2) as shown below:

(H7)x6	Screw 1/8" x 2"L	0
(H8)x3	Screw 1/8"x 1-5/8"L	0
(H9)x1	Screw Driver	0




Step 3: Attach Center Support (P4) to Top (P1), as shown below:

(H1)x4	Bolts Ø1/4" x 3/4"L	0
(H2)x4	Lock Washers 1/4"	0
(H3)x4	Flat Washers 1/4"x16	0
(H4)x1	Allen Wrench	0



Step 4: Attach Leg Frame to Center Support (P4), and attach the Nut (H6) to Center Support (P4) as shown below:


(H1)x1	Bolts Ø1/4" x 3/4"L	0
(H2)x1	Lock Washers 1/4"	0
(H3)x1	Flat Washers 1/4"x16	0
(H4)x1	Allen Wrench	0
(H5)x1	Flat Washers Ø30	0
(H6)x1	Nut	0



Step 5:

1. Turn the assembled table to an upright position.
2. Assembly is complete.

** Usage Warning: Per the instructions below, the stool must be adjusted to either the High position, or Low position for stability. If stool is NOT in either High or Low position, it is not stable and could lead to potential product damage, or bodily injury.*



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO ENSURE THAT ALL HARDWARE IS KEPT TIGHTENED.

Thank you for your purchase