

# ASSEMBLY INSTRUCTIONS

## Description: Elmwood Dining Table





### Important safety instructions:

- Please read carefully all instructions before assembling.
- For your safety and ease, assembly by two or more adults is recommended.
- Keep instructions for future use.









### Pre-assembly:


- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- Remove all parts and hardware from box along with any protective packaging.

### Parts List

Item	Description		QTY
P1	Table Top		1
P2	Legs A		2
P3	Legs B		2
P4	Shelf with frame		1

### Hardware List

Item	Description		QTY
H1	Small Bolt Ø1/4"*1-3/4"L		8
H2	Small Lock Washer 1/4"		8
H3	Small Flat washer 1/4"		8
H4	Small Allen Wrench 1/4"		1
H5	Big Bolt Ø5/16"*2"L		8
H6	Big Lock Washer 5/16"		8
H7	Big Flat washer 5/16"		8
H8	Big Allen Wrench 5/16"		1



### Assembly Procedures:

Step 1. With one person to help, loosely attach the legs A (P2) and legs B (P3) to the shelf with frame (P4) as shown below image 1.






- (H1)x8 Small Bolt Ø1/4"\*1-3/4"L 
- (H2)x8 Small Lock Washer 1/4" 
- (H3)x8 Small Flat washer 1/4" 
- (H4)x1 Small Allen Wrench 1/4" 

Image 1



Step 2. Turn over the table top (P1) on a flat, soft surface such as a carpet or cloth to prevent scratching the finish. Attach the assembled legs A (P2) and legs B (P3) to the bottom of table top (P1) as shown below image 2.

(H5)x8 **Big Bolt Ø5/16"×2"L**



(H6)x8 **Big Lock Washer 5/16"**




(H7)x8 **Big Flat washer 5/16"**




(H8)x1 **Big Allen Wrench 5/16"**



Image 2



Step 3. Securely tighten all bolts, then turn the assembled table to an upright position. Assembly is complete. **Failure to follow these instructions may cause the bolts to misalign during assembly.**



ADDITIONAL NOTE ABOUT SAFETY: BOLTS MAY LOOSEN DURING NORMAL EVERYDAY USE. THEY SHOULD BE PERIODICALLY INSPECTED AND RE-TIGHTENED TO PREVENT DAMAGE OR INJURY. ALWAYS CHECK TO BE SURE THAT ALL HARDWARE IS KEPT TIGHTENED.

**Thank you for your purchase**